



quick start guide

model GLS 4.0



headphone power and volume adjustment



1. power on transmitter

Press the power button on the transmitter. A blue LED will start blinking.



2. connect headphones and transmitter

Press any button on the headphones. A blue light will blink and will turn solid blue once they have been successfully connected. Repeat until desired number of headphones are connected.



3. adjust volume for each headphone

Press the (+) button (VOL+) to increase volume or the (-) button (VOL-) to decrease volume.



There are 4 major volume levels that can help you determine volume level by color and increasingly rapid flashing. From lowest to highest they are blue, green, yellow, red.



4. connecting audio sources

Plug your preferred microphone into the "mic in only" port on the transmitter to amplify your voice. Plug in your preferred audio source where its says "audio in only" using the aux or RCA cord. Use both ports if appropriate.

having difficulty?
let us help you!

(855) 938-7686 – ext. 2
support@eversoundhq.com